
MODEM BASICS

- Please ensure that the MODEM is as high up as possible on the wall and near a window
- Do not install under metal sinks or cupboards
- Ensure the aerial is upright and not installed sideways
- Keep in mind that the unit needs to communicate with mobile networks, so the signal needs to be good.


RESET MODEM

- Please ensure the modem and aerial are not covered or obstructed by items (clothing, mops etc)
- Unplug the cable. Wait 5 min. Replug into the modem. It will now reconnect with the network









INDICATOR LIGHTS

• RED light ON : Power

• GREEN light FLASHING : Connecting to the network

• GREEN slow PULSE : Connected



01524 555 929

Should you have any further queries, or require any additional information, please contact us.

